## COYOTE® Splice Tray









## **Selection Chart**

			103			
Short Splice Trays & Closures	COYOTE RUNT	COYOTE Expanded RUNT	COYOTE In-Line RUNT	COYOTE Terminal Dual Chamber*	COYOTE PUP	COYOTE Multi Purpose Closure (MPC)
Standard Tray (12 Splice Count) 80806033-12A	2 Trays 24 Max Splice Count	4 Trays 48 Max Splice Count	3 Trays 36 Max Splice Count	6 Trays 48 Max Splice Count	5 Trays 60 Max Splice Count	4 Trays 48 Max Splice Count
Standard Tray (24 Splice Count) 80806033-24A	2 Trays 48 Max Splice Count	4 Trays 96 Max Splice Coun	3 Trays 72 Max Splice Count	6 Trays 96 Max Splice Count	5 Trays 120 Max Splice Count	4 Trays 96 Max Splice Count
Standard Tray Mechanical & Fusion (12 Splice Count) 80806033	2 Trays 24 Max Splice Count	4 Trays 48 Max Splice Count	3 Trays 36 Max Splice Count	6 Trays 48 Max Splice Count	5 Trays 60 Max Splice Count	4 Trays 48 Max Splice Count

Note: \* Total capacity of dual chambers



## **COYOTE®** Splice Tray









## **Selection Chart**

Long Splice

Trays & Closures



COYOTE



COYOTE



COYOTE **Splice Case** 



COYOTE Splice Case



Low Profile Tray (36 splice count) 8001127 (w/ plastic splice blocks) or 80807769 (blank)

6 Trays 216 Max Splice Count

11 Trays 396 Max Splice Count

6 Trays 216 Max Splice Count

9 Trays 324 Max Splice Count



Standard Tray (36 Splice Count) 80805514 (w/ elastomer splice blocks), 80805110 (w/ ridgid slots), or 808055

4 Trays 144 Max Splice Count

8 Trays 288 Max Splice Count

4 Trays 144 Max Splice Count

7 Trays 252 Max Splice Count

